
Electronic Microscope

User Manual

Contents

Product Installation

Packing List.....	1
Hardware sketch map.....	1
Software installation.....	1

Product Introduce

Function.....	2
Computer request.....	3
Notice.....	3
How to know your PC support USB 2.0.....	3
How to know the Win2K system is SP4 or WinXP is sp1.....	4

Software Introduce

How to use the software.....	5
------------------------------	---

Product Installation

A.Package Contents

Host: 1 pcs
USB cable: 1 pcs
User guide: 1 pcs
Software CD: 1 pcs

Please contact your retailer if any of the items is damaged or missing.


C.Software installation

1.Please put the software CD into CD-ROM, later on will autorun the installation interface.You can install all item only click button.

Notice: Please must install "DirectX9.0C" "DivX412Codec" and "driver" ,if your system is Win2K, please install Sp4 package. if your system is WinXP, please make sure is Sp1 and up.

2.If you finished installation, your desktop will found “  ” icon.

B.Hardware sketch map



Product Installation

3.If display the following information,please check the connectionfrom host to PC and driver.



Product Introduce

A.Function:

Microscope magnification: 30X max. Use itto check circuitboards and pins clearly without other tools.

Independently developed display software, supporting image capture、record、instant image print etc.You can save circuitimages captured andthe whole operatingprocess by easy clicks.

This Microscope is most suitable for: circuit trouble check、weld empty check、FPC / circuit copy、demo etc., andwidely used in the domain ofelectronics、medical treatment、education etc.

Product Introduce

B.Computer request


- 1、 CPU: Intel Pentium III 600 and above
- 2、 Mainboard: Support USB 2.0
- 3、 Video card: support AGP(databuffer size: 8M and up)
- 4、 System: Windows 2000(sp4) or Windows XP (sp1 and up)
- 5、 Memory: 128M and up
- 6、 CD-ROM or DVD-ROM

C、 Notice


- 1) Please use the mainboard of support USB 2.0, otherwise the displayeffect will be bad.
- 2) if you are using USB 1.1 ,you can buythe USB 2.0 conversion card.

How to know your PC support USB 2.0

Please into "Computer monitor"; as pic



How to know the Win2K system is SP4 or WinXP is sp1



How to use the software

1. Open the window;as pic
2. Video Capture Filter
- 2.1 Please click "  " then open the following window ,as pic


- 2.2 Please drag the slider you can see the list effect

3. How to change the language;as pic:




- 4.FullScreen: Please click "  "

5. How to capture the image



A. First set the path for the file;as pic



If you want to change path,please click "Browse"





If you want to change the filename,please input the new filename in prefix name item.

B. Then you can click "Capture" button ,moment you will browse the image in image preview area;as pic.



You can use the hotkey to finished operation;as pic




If you doubleclick it will open new window to list it.

6. How to video record.

Please click "Record" button,then open the following window; as pic:



Please input the filename then click "save". The process is start. If you want to stop please click "Stop".



7. How to print the current frame.

Please click "[Operation]/[Print current image]"; aspic:

